



CL-441-BK CL-454-BL
CL-455-RD CL-456-RD
CL-485-BK CL-486-BL
CL-487-RD CL-488-PK

NON-RESETTABLE
NO REINICIABLE
NON RÉINITIALISABLE

To Open:

Remove the factory set combination tag attached to the lock. Rotate dials to the word on the tag and open the cable.

To Lock:

Push cable end into lock, then rotate dials to a random setting. Keep your word tag in a safe place. This is the only word that will unlock your lock.

Para abrir el candado:

Retire la etiqueta con la combinación de fábrica que está sujeta al candado. Gire las ruedas selectoras hasta formar la palabra de la etiqueta y abra el cable.

Para cerrarlo:

Empuje el extremo del cable dentro del candado, luego gire las ruedas selectoras hasta formar cualquier combinación al azar. Guarde la etiqueta que contiene la palabra en un lugar seguro. Ésta es la única palabra que abrirá su candado.

Pour ouvrir:

Enlevez l'étiquette de la combinaison réglée à l'usine et fixée au verrou. Tournez les cadrans jusqu'au mot sur l'étiquette et ouvrez le câble.

Pour verrouiller:

Poussez l'extrémité du câble dans le verrou puis, tournez les cadrans à un paramètre au hasard. Conservez l'étiquette de votre mot dans un endroit sûr. Ce mot uniquement déverrouillera votre verrou.